



# OAD & OAP Toolkit

with **Accu-Drive®** Technology  
Part No. / N° De Pièce / No. De Parte **08006**

## Kit contains / L'ensemble contient / El kit contiene:

- › 1-33T spline pulley socket / 1 douille cannelée (33 cannelures) / 1 llave punta estriada (33 T)
- › 1-17mm hex pulley socket / 1 douille hexagone (17 mm) / 1 dado hexagonal (17 mm)
- › 1-10mm triple square shaft bit / 1 mèche à triple carré (10 mm) 1 llave filamento triple (10 mm)
- › 1-T-50 shaft bit / 1 mèche T-50 / 1 dado T-50
- › 1-10mm female hex shaft bit / 1 mèche femelle hexagone (10 mm) / 1 llave hexagonal hembra (10 mm)

**Five-piece kit for removal and installation of overrunning alternator decoupler pulley (OAD) and overrunning alternator pulley (OAP).**

Ensemble de cinq pièces pour la pose et la dépose d'une poulie à roue libre d'alternateur (OAD) ou de découpleur d'alternateur (OAP).

Kit con 5 piezas para el montaje y desmontaje de polea libre desacopladora para alternador (OAD) y la polea libre del alternador (OAP).

**WARNING:** This product contains chemicals known to the state of California to cause cancer and birth defects or other reproductive harm.

The content of this publication is not legally binding and is provided as information only. The trademarks displayed in this publication are the property of Continental and/or its affiliates. Copyright ©2016 ContiTech. All rights reserved.

### Contact

ContiTech  
NAFTA Headquarters  
703 S. Cleveland Massillon Road  
Fairlawn, OH 44333-3023 U.S.A.  
1-800-235-4632  
FAX 1-800-228-3148

### Canada

1-888-275-4397  
FAX 1-888-464-4397

### Mexico

1-800-439-7373  
FAX 1-800-062-0918